


## Software-Update Version 1.0.10 manual

In order to keep your door systems updated, please proceed with the following changes.

1. Exchange CPU -Z1 (E60-0228-10) by the new one you already received.

### Front view



## Rear view

Frequency converter  
(N60-0402)

Mains filter (N60-0405)

Mains connection  
230 V AC –X103


24 V DC power supply unit  
(N60-0583)

Relay K1  
(N60-0560)

Service power outlet  
max. 300 W  
(N60-0694)

Collector (230VAC)-X105

Potentiometer for  
24V DC adjustment

















Readout the parameter settings before exchanging, in order to transfer these to the new CPU.

The following chart shows the setting entries:

The **standard** values are shown here, they may however vary.

#### Parameters

Parameter designation	Symbol	Description	Unit	Range	Original setting	Palm	Central system	Learning cycle	Original setting	Wiring
Current error status		Error list				-	-	-	-	-
Door diameter		Door diameter	mm	2000 .. 6500	(system learns diameter)	-	-	C	-	-
#el. locking devices		Electromechanical bolt locking device no = 0, yes = 1		0 .. 1	0	U	U	-	C	-
Hold after stop		Time until the el. brake is released after an Emergency Stop 0 = brake never released, 1 - 9 = after... sec.	sec	(0 .. 9) sec	1	U	U	-	C	-
#X-Pos Auto 1 - 2		Number of starting positions in Automatic 1 or 2		2 .. 5	2	U	U	-	C	-
SlowStop canopy		SlowStop time of canopy-integrated sensors	sec	(0 .. 15) sec 16 = ∞	16	U	U	-	C	-
SlowStop wing		SlowStop time of wing sensor	0.1 sec	(0 .. 15.9) sec 16.0 = ∞	16.0	U	U	-	C	-
Hold after stop		Time until the door starts after a safety stop	0.1 sec	(0 .. 9.9) sec	1.0	U	U	-	C	-
Sec. area stop		Detection range of canopy-integrated sensor in security area for SlowStop	mm	(d * (pi/3) .. 500) mm	700	U	U	-	C	-
Summer configuration		Starting-positions: 0°/180°			(system reads X-positions)	-	-	-	-	U
Starting position Summer		Starting-positions: 90°/270° [0], 60°/240° [1]		0 .. 1	0	U	U	-	C	-
PosV after safety stop		Time system operates in positioning speed after leaving the stationary position following a safety stop	0.1 sec	(0.0 .. 2.9) sec	1.0	U	U	-	C	-
A/M lighting		Automatic/manual lighting control		0 ... 1	0 (auto)	U	U	-	C	-
FUT warm air curtain		Follow-up time of warm air curtain	sec	0 ... 600	10	U	U	-	C	-

#### Caption:



U = adjustable value

C = resettable value


- = non-adjustable value

2. Reconnect **NC** at **OUT4** to **NO** at the locking module „IL1“.


**OLD:**




**NEW:**



Datum	26.09.2011	KTC-2 (MS9)	Drahtver.	Erstellt durch		Verriegelung drehender Teil	G4/47-2046	Blatt	14
Zeichn.	mechanisch								
Name	Utop								



3. Please check if terminals X101:59 and 60 are connected to -IL1(see picture).




**For doors with integrated sliding doors bridge -X101:+ with 60, please!**

4. Change the following in the UPS monitoring circuit:


- New terminal strips –X105
- Additional relay K7 (230VAC-version)

Exchange the old terminal strip –X105 by the new one and install the additional relay K7. Wiring as follows:



**NEW "K7"**









5. Carry out the wiring as follows if the door system is furnished **with** UPS:


If a UPS is joined up in circuit, put the inlet connector for non-heating apparatus from -X103 into the UPS and the other 230VAC adapter cable to be connected between UPS and control system at -X103.



6. Is the door system **without** UPS, please proceed with the wiring as follows:



7. Re-wire the inputs in the rotating part „I1“ here IN10+11 as follows:




8. Adjust the crossover cable from the MS9 control system to ES200.

Connect the delivered 2-wire cable „33.1 ES200-Not Halt“ with the terminals – X101:33/34 and ES200:32/33. Remove bridge (ES200: 32-33) at ES200 beforehand.

**New connection**

**Terminal “47” is connected to +24VDC**




9. Change of emergency-stop logic. The ES200 drive will be stopped by emergency-stop when activated.

The auxiliary contactor **N60-0460** must be put on „K1“ contactor.



Normally open K1:53 and 54 to be connected to the terminals –X101:33 and 34 as follows:




If all changes are carried out, please put the door system back into operation as follows:


## 10. Initial operation of the door system

- The emergency-stop is activated
- The control system is switched on
- Program switch KT on Automatic 1
- The curved sliding door wings and the showcase doors are closed
- The frequency converter and the CPU are parameterized
- Door system is in summer position
- Push Select push button and keep it pushed for 4 sec
- Release emergency-stop
- Learning cycle starts

### Indication of learning cycle and positioning drive

During the learning cycle and positioning drive the display shows a gyro.



- Door system rotates in positioning speed
- The door system turns for min. 1 rotation
- Afterwards the door system restarts with its regular function
- Check all functions according to the original manual and/or the attached chart.
- Check if the control system has learned the correct diameter. Check via parameter .

## 11. Testing of changes

- Door systems with UPS: Revolving door has to rotate in program switch position Auto1 or Auto2 into summer position and stop there.
- Program switch position in „Summer“ and the sliding door is in operation (test all program switch positions of the sliding door), sliding door must stop in case the emergency-stop is activated and remain in this position as long as this is activated.
- Check all revolving door functions again.

Done