

Information Bulletin

08242021-1

LA GARD 700 Series: Installation Best Practices

The following steps are intended to provide further guidance on the process for installing and new lock and keypad for our 700 Series Solution. Please employ the steps in the order set out below for a proper installation:

700 Series Order of Setup Operation

1. Physically Mount the Keypad.
NOTE: Do Not install batteries or connect to power.
2. Physically Mount the Lock Body.
3. Connect the Keypad cable to the Lock.
NOTE: Do not pull or over stretch the Keypad cable as it may be pulled out of the internal connection port.
- 4 Install batteries in the Entry Unit.
5. Install (Electronically Pair) and Program the system as instructed in the System User Guide.
([Document 7040.0721](#))

Please note: If programming lock and then shipping to site, disconnect power and do not reapply/insert battery power until all systems are mounted and properly plugged in. If keypad does not immediately respond please allow 30 to 45 seconds for entry to properly pair with lock body.

For further information please refer to the Safe Lock Installation Guide ([Document 7034.0621](#)).

