

# 1240 DOOR CO-ORDINATOR



## Fitting Instructions

- 1) Mount door co-ordinator to transom.
- 2) Install wear plate on door 'A'.
- 3) Drill hole in door 'B' for striker plate centre screw, 50mm from door edge and on same centre line as wear plate screws.

Adjust striker plate until its end clears door 'A' by 3mm when door 'A' is held open by co-ordinator.

When satisfied with adjustment, tighten screw firmly and install other 2 screws.

- 4) Position of arm may be changed by winding the adjustment screw in or out.

**Note:** When installed in conjunction with a door seal, a packing plate may be required.

