



MOUNTING INSTRUCTIONS FOR EM-MAG1500

Step 1) **If with Security Plate:**

- Fold template along **D** dotted line.
- Place template against door and head frame.
- Drill 4 holes (**A**) for door and 2 holes for head frame as indicated on the template.

If without Security Plate:

- Fold template along **C** dotted line.
- Place template against door and head frame.
- Drill 3 holes (**B**) for door and 2 holes for head frame as indicated on the template.

Step 2) **Mount Armature Plate per Installation Instructions.**

Note: Do not over tighten armature plate. It must remain moveable to allow surface alignment with mechanical electromagnetic lock face.

When properly installed, the ends of the armature plate allow a slight movement but the plate will feel secure when grasped at the bolt. There should be no movement to the mounting bracket or housing of the mechanical electromagnetic lock.

Step 3) **Securing the Mounting Bracket per Installation Instructions:**