

78091 Arator

1 Important Instructions




- The locking mechanism works smoothly. No force should be applied. This should be particularly avoided when inserting the key in the lock.
- Opening the lock with a damaged key can result in damage to the lock.
- The lock must not be lubricated.
- The lock may only be installed by specialist personnel and only opened by the manufacturers. Unauthorised opening will lead to invalidation of any guarantee claims.
- Only original Kaba Mauer keys are to be used should additional keys be required, as otherwise no guarantee claims may be raised.

2 Opening

- Insert key in the keyhole as specified in the table below and turn in the appropriate direction until stop position is reached (approx. 150°).

Lock Installation Position	Key Insertion Position	Direction of Turn
Bolt left, keyhole horizontal	(Long) bit left	Clockwise

Diagram 1: Double-bit key



- The key cannot be removed when the lock is open.

3 Locking

- Turn the key back to the original position.
- The key is to be removed after locking and kept in a safe place where it is not accessible to unauthorised persons.

Should you have any questions regarding our products, please contact your safe manufacturers/specialist dealers.

Safe Manufacturers/Specialist Dealers: