



78084/86 Lock for Letter Boxes



78084



78086

Lock Installation Position 78084	Lock Installation Position 78086
Bolt left, keyhole vertical	Bolt left, keyhole horizontal

1 Important Instructions



- The locking mechanism works smoothly. No force should be applied. This should be particularly avoided when inserting the key in the lock.
- Opening the lock with a damaged key can result in damage to the lock.
- The lock must not be lubricated.
- The lock may only be installed by specialist personnel and only opened by the manufacturers. Unauthorised opening will lead to invalidation of any guarantee claims.
- Only original Kaba Mauer keys are to be used should additional keys be required, as otherwise no guarantee claims may be raised.

2 Opening

- Insert key in the keyhole (see Fig. 1, Fig. 2).




Fig. 1: 78084




Fig. 2: 78086

- Turn in the appropriate direction until stop position is reached.
- The key cannot be removed when the lock is open.

3 Locking

- Turn the key back to the original position.
- The key is to be removed after locking and kept in a safe place where it is not accessible to unauthorised persons.

Should you have any questions regarding our products, please contact your safe manufacturers/specialist dealers.

Safe Manufacturers/Specialist Dealers: