


WN 058125-45932  
09/11


**TL-S TMS 2 Basic**  
+ 1x TV 1xx DCW®  
+ 2x ST 3x DCW®



S2 = Komponentenadresse/  
Device address

Schalter/Switch	Adresse/ address
1 0 0	1
1 0 1	2
0 1 1	3
1 1 1	4

TL-S TMS 2 Basic  
 + 2x TV 1xx DCW®  
 + 2x ST 3x DCW®



S2 = Komponentenadresse/  
Device address

Schalter/Switch	Adresse/ address
0 0	1
1 0	2
0 1	3
1 1	4

Änderungen vorbehalten  
 Subject to change without notice  
**2**