

Cleaning & Preventative Maintenance for Overhead Door Closers

Atmospheric deposits, sulphurous acids, carbon dioxide and other chemicals in the air will discolour and tarnish any decorative finish over a period of time and cause corrosion. Regular maintenance prevents atmospheric deposits building up and attacking the metal.

Our closers and closer covers are made from durable material, which requires minimum attention but must not be neglected. A simple cleaning program should be implemented, in order to maximize the performance and life cycle thus enhancing the aesthetic value and prolonging the 'life' of the closers.

Wash the covers and arms (or slide arms), on a monthly basis with a mild detergent warm water and a soft sponge followed by a clear water rinse, finally wiping dry with a soft duster or chamois leather. This will be adequate to keep this system free of dirt and grime.

Important Do not use any form of abrasive cleaner or cleaning material on any part of the dormakaba products.

When using any detergents, rubber gloves and eye protection should be worn to protect the skin and eyes from its contact with harmful chemicals.

Requirement	Suggested Method
Routine cleaning	Soap or mild detergent in warm water rinse and wipe dry.
Fingerprints	Detergent and warm water, alternatively, Hydrocarbon solvent.
Oil & Grease marks	Hydrocarbon solvent.

All moving parts should be kept free of dirt and debris at all times, which will eliminate possible jamming of components.

Please ensure all fixings are tightened correctly, these should be checked on a regular basis.

Note: In accordance with **BS8214**, manual doors should be examined at six month intervals with particular attention being paid to panic and emergency exit bars, hinges and pivots and door closers.