


LATCH MONITOR SWITCH MODULE for ES96F ELECTRIC STRIKE

**IMPORTANT:** 3 ribs on the LM lever may require trimming for its proper engagement with 3/4" latch bolt.

Improved design to accommodate  
1/2" - 3/4" latch throw.



Step 1: Carefully remove faceplate from strike insert.

Make sure the deadbolt and deadlatch alignments don't change.

Step 2: Move the door towards the strike so that the latch touches the keeper.

Step 3: Mark latch limit lines on keeper (Fig.1).

Step 4: Open the door, mount the Latch Monitor Module on the strike housing so that it is between the latch limit lines marked on keeper.

Step 5: Make electrical connection, position the faceplate onto the strike and secure to the frame.

NOTE: To avoid pinching, ensure wires run through wiring channel before inserting strike into frame (Fig. 2).

Step 6: Test the door to ensure the latch depresses the LM lever. If the latch doesn't depress the LM lever, the ribs must be trimmed with side cutters (Fig. 3).

